

Di-LOG

...measurably better

operating manual

DL7103

SOUND LEVEL METER



CE

CE IEC 651 TYPE II

Safety Information

Read the following safety information carefully before attempting to operate or service the meter.

Use the meter only as specified in this manual; otherwise, the protection provided by the meter may be impaired.

Environment Conditions

1. Altitude up to 2000 meters
2. Relatively humidity 90% max.
3. Operation Ambient Temperature 0~40°C

Maintenance & Cleaning

1. Repairs or servicing not covered in this manual should only be performed by qualified personnel.
2. Periodically wipe the case with a dry cloth. Do not use abrasives or solvents on this instruments.

Safety Symbols



Meter is protected throughout by double insulation or reinforced insulation.

When servicing, use only specified replacement parts.



Compliance with relevant EMC directories.

General

To ensure that you can get the most from this instruments, we recommend that you read and follow the manual carefully before use.

This unit conforms to the IEC651 type 2, ANSI S1.4 type 2 for Sound Level Meters.

This Sound Level Meter has been designed to meet the measurement requirements of safety Engineers, Health, Industrial safety offices and sound quality control in various environments.

- Ranges from 30dB to 130dB at frequencies between 31.5Hz and 8 KHz.
- Display with 0.1dB steps on a 4-digits LCD.
- With two equivalent weighted sound pressure levels, A and C.

Specifications

Standard applied:

IEC651 type 2, ANSI S1.4 type 2

Frequency range:

31.5Hz~8KHz

Measuring level range:

30~130dB

Frequency weighting:

A/C

Microphone:

1/2 inch electric condenser microphone

Calibration:

Electrical calibration with the internal oscillator (1kHz sine wave).

Display:

LCD

Digital display:

LCD4 digits

Resolution:

0.1dB

Display Up data:

0.5 sec.

Time weighting:

FAST (125mS), SLOW (1 sec.)

Specifications

Level ranges:

Lo: 30-100dB

Hi:

60-130dB

Accuracy:

+1.5dB (under reference conditions).

Alarm function:

"OVER" is shown when input is out of range.

Maximum hold:

Hold readings the Maximum Value, with decay
< 1dB / 3 minutes.

Auto power off:

Meter automatically shuts down after approx. 15
minutes of inactivity.

Power supply:

One 9V battery, 006P or IEC 6F22 or NEDA 1604.

Power life:

About 50hrs (alkaline Battery).

Operation temperature:

0 to 40°C (32 to 104°F)

Specifications

Operation humidity:

10 to 90%RH

Storage temperature:

-10 to 60°C (14 to 140 °F)

Storage humidity:

10 to 75%RH

Dimensions:

210(L) X 55(W) X 32(H)mm

Weight: 230g (including battery)

9V battery, carrying case, Instruction manual.

Controls and Inputs



Controls and Inputs

1. Windscreen: If you operate at wind speed over 10m/sec, please put protective accessories in front of the microphone.

2. Display

Symbol	Function
LCD	4 digits
MAX	Maximum Value hold
OVER	Over range
F	Fast response
S	Slow response
A	A-Weighting
C	C-Weighting
Lo	Low Range (30~100dB)
Hi	High Range (60~130dB)
BAT	Low-Battery

3. Power ON/OFF Button:
Turn the meter power ON/OFF.

4. Backlight Button:
Turn the meter backlight ON/OFF.

5. A-weighting / C-weighting select button

A: A - Weighting. For general sound level measurements.

C: C - Weighting. For checking the low-frequency content of noise.

(If the C-Weighted level is much higher than the A-Weighted level, then there is a large amount of low-frequency noise).

Controls and Inputs

- F/S** 6. Time weighting select button:

F (fast response):
for normal measurements (fast varying noise).

S (slow response):
for checking average level of fluctuating noise
- Lo/Hi** 7. Level range select button:

Lo: 30~100dB;
Hi: 60~130dB

When "OVER" is indicated, the ranges switch to another range for measurement.
- Max/ Hold** 8. MAX/ Hold button

The max. Hold position is used to measure the maximum level of sound. The maximum measured level is updated continuously. Press once again the button, will release the hold and allow a further measurement.

Data Hold button: Press and hold the Button for over 2 seconds to turn data hold function on or off. The hold function freezes the reading in the display.
9. Microphone:
1/2 inch Electric Condenser microphone.
10. Battery Cover

Replacing & Installing the Battery

Battery loading:

Remove the battery cover on the back and put in one 9V Battery.

Battery Replacement:

When the battery voltage drops below the operating voltage, mark "BAT" appears. If it appears, battery should be replaced with a new one.

Operating Precautions

1. Wind blowing across the microphone would create additional extraneous noise.
If using the instrument in the presence of wind, it is advisable to mount the windscreen to avoid extraneous signals.
2. To achieve more accurate measurement, use an extension cable to separate the Microphone from the main body so that the effect of unexpected sound reflection can be eliminated.
3. Calibrate the instrument before operation if the instrument is not in use for a long time or operated at bad environment.
4. Do not store or operate the instrument at high temperature and high humidity environment.
5. Keep microphone dry and avoid severe vibration.
6. Take the battery out and keep the instrument in low humidity environment. When not in use.

Measurement

1. Open battery cover and install a 9-volt battery in the battery compartment.
2. Turn on power and select the desired response Time and weighting. If the sound source consists of short bursts or only catching sound peak, set response to FAST. To measure average sound, use the slow setting. Select A- weighting for general noise sound level and C-weighting for measuring sound level of acoustic material.
3. Select desired Level.
4. Hold the instrument comfortably in hand or fix on tripod and point the microphone at the suspected noise source, the sound pressure level will be displayed.
5. When MAX (maximum hold) mode is chosen. The instrument captures and holds the maximum noise level for a long period using any of the time weightings and ranges.
6. When HOLD (data hold)mode is chosen. The hold function freezes the reading in the display. Press the HOLD button momentarily to activate or to exit the HOLD function.
7. Turn OFF the instrument and remove and remove battery when not in use.

Calibration Procedures

Using a standard Acoustic Calibrator
(94dB, 1kHz Sine wave)



Screwdriver



Calibration Procedures

1. Make the following buttons and function switch settings.

Display: dB, A, Hi or Lo, F

Function: A-Weighting

Response Time: FAST

Level range:

30 to 100dB (Lo) or 60 to 130dB (Hi)

Measurement mode:

MAX Hold and Data Hold Mode function disable.

2. Insert the microphone housing carefully into the insertion hole of the calibrator.
3. Open battery cover and remove the battery to adjust the CAL94dB potentiometer of the unit. The level display will indicate the desired level.

Warranty & Maintenance

24 Month Warranty

Di-Log instruments are subject to stringent quality controls. If in the course of normal daily use a fault occurs we will provide a 24 month warranty (only valid with invoice).

Faults in manufacture and materials defect will be rectified by us free of charge, provided the instrument has not been tampered with and returned to us unopened.

Damage due to dropping abuse or misuse is not covered by the warranty.

Outside the warranty period we offer a full repair and re-calibration service.

Maintenance

WARNING Do not attempt to repair or service you meter unless you are qualified to do so and have the relevant calibration, performance test and service information. To avoid electrical shock or damage to the meter do not get water inside the case.

Periodically wipe the case with a damp cloth and mild detergent. Do not use chemical solvent.

Clean the input terminal with cotton bud, as dirt or moisture in the terminal affect readings.

Di-Log Test Equipment

28 Wheel Forge Way,
Trafford Park,
Manchester
M171EH, UK

tel: + 44 161 877 0322

fax: + 44 161 877 1614

email: sales@dilog.co.uk

website: www.dilog.co.uk

Voltage 16th Edition Phase Rotation Clamp
kHz
Resistance Continuity Loop
Phase Rotation Portable

Clas
Mul
ge 1
AC/DC
se

Ed
ista
on